


# *QUICK START GUIDE*


# **VECTOR**

BLUETOOTH® VIBRATION SPEAKER

## TOUCH CONTROLS



## INPUT/OUTPUT



## HOW TO PAIR

Connect any compatible Bluetooth device to the speaker by following these steps:

- Press and Hold the ON/OFF button for 3 seconds to turn on the speaker.
- Go to Bluetooth settings on your device and connect to *VECTOR*.

## USING THE BUILT-IN MICROPHONE

When the speaker is connected to a compatible Bluetooth device with a phone feature, simply touch Play/Pause/Answer Call to answer an incoming call.

Now you can use the built-in microphone on the *VECTOR* to talk more freely.

# TRUE WIRELESS STEREO

You can wirelessly connect with an additional VECTOR by following these steps:

- Make sure the first speaker is turned ON and paired to a compatible Bluetooth device.
- Then, power on the second speaker and tap **Play/Pause** two (2) times on the second speaker.
- A confirmation sound is played. Both speaker should now be paired and in **True Wireless Stereo** mode.
- To unpair, tap **Play/Pause** two (2) times again.

The logo for PICZO, featuring the word "PICZO" in a bold, black, sans-serif font. The letter "P" is stylized with a curved top.

The Bluetooth word mark and logos are registered trademarks owned by Bluetooth SIG, Inc.

Piczo is a registered trademark of Swede Invent AB, registered in Sweden.  
Distributed by Swede Invent AB, Säterivägen 16, 65341 Karlstad, Sweden.  
© 2019 All Rights Reserved.